

INPUT
J1
Channel High / Low
K1
K2
Booster
HV1
V1A ECC83
V1B ECC83
V2A ECC83
V2B ECC83
V3A ECC83
V3B ECC83
HV2
HV3
High Channel
Low Channel
TREBLE
BASS
MIDDLE
TO FXLOOP / POWERAMP
K3
HT
V1" ECC83
V2" ECC83
V3" ECC83
FINDER-30.22
DUAL_LED
9077-1
PG203J
+6V
6V_GND
Pin 2: Boost
Pin 5: Channel