

HV1
HV2
HV3
Booster
Channel High / Low
High Channel
Low Channel
INPUT
V1A ECC83
V1B ECC83
V2A ECC83
V2B ECC83
V3A ECC83
V3B ECC83
TREBLE
BASS
MIDDLE
TO FXLOOP / POWERAMP
VTL5C1
LDR1
Z0
TT-MIDI-MODUL
FINDER-30.22
+5V
A1_GND
A5_GND
A2_GND
5V_GND
V1" ECC83
V2" ECC83
V3" ECC83
HT
PG203J
TT-MIDI: I1
TT-MIDI: I2
I1: Channel (Low)
I2: Channel (High)
I5: Boost
Z1: MIDI Store
MIDI Store LED
TT-MIDI:
Channel 1 (A1): Low Channel
Channel 2 (A2): High Channel
Function (I5): Boost