INPUTS

VOLUME

TONE*

CUT

MASTER

INDICATOR

STANDBY

POWER

shielded wire

R1

C12

R16

R15

C4

C5

C6

R7

R12

R4

C1

C2

R6

R5

C3

R23

C16

C7

R9

R10

R11

C9

R14

R17

C10

R8

R13

C11

C15

R22

R18

C13

R19/5W

C8

R20

IND1

IND2

N

L

Star Ground

Speaker Jacks

HT Fuse

C.T. Heater

from PT

H2

H1

H4

H3

C.T. HV winding

50+50 uF/500V

R21/5W

R3

H1

H2

V1: EF86

V2: 12AX7/ECC83

V4+V3: EL84

Heater V1, V2

V5: EZ81

*TONE SWITCH / Backview

VOL IN

C3

C4

C5

R7//C6

3 pole / 4 position rotary switch

16 Ohm OT

8 Ohm OT

Star Ground

COM OT

Speaker Output

Connections under the board

from OT

Star Ground

PE

HT Fuse