
"headroom" version:

- bridge B2
- use C7
- use R4 and R8
- B1 open

bridge B3 if necessary for
the applied grounding scheme

"straight" version:

- bridge B1
- bridge R4
- C7 can be bridged
- B2 open



Tube–Town
LNDBoost v1.3B

03.2021

Tube–Town Forum

Sheet: /
File: Boost LND150_headroom.sch

Title: LNDboost

Size: User	Date: 2021–03–19	**Rev: 1.3B**
KiCad E.D.A. kicad (5.1.6–0–10_14)		Id: 1/1